

What is the proper way to do a carbon monoxide alarm test?

The proper way to do a carbon monoxide alarm test is to press and hold the Test Button on the front of the alarm until the alarm sounds. Be sure you hold the button down long enough. It can take up to 20 seconds for the alarm to respond to your test.